Installing REGAL Knockdown Frames To Fabricated Timber or Metal Stud Walls

1. Leave a correct stud opening (add 40mm to door width & 45 mm to door height).

   Example: for a standard (820mmx2040mm) door, the stud opening should be (860mmx2085mm)

2. Assemble the head and the jambs into position.

3. Fix the door frame together by screwing the FOUR pre-drilled pilot holes located at the top of the frame.

4. Check the frame is squared and leveled.

5. Screw the fame to the stud work through the counter-sunk holes.

6. Fill screw holes with quality metal body filler and sand back for painting.

Please be advised this is a guide only and any installations should be done by a professional.
JDS Metal Doorframes hold no responsibility if knockdown doorframes are installed incorrectly.